

This presentation is released under the terms of the **Creative Commons Attribution-Share Alike** license.

You are free to reuse it and modify it as much as you want as long as:

- (1) you mention Ian Howard and Séverin Lemaignan as being the original authors,
  - (2) you re-share your presentation under the same terms.

You can download the sources of this presentation here: github.com/severin-lemaignan/module-introduction-sensors-actuators

# ROBOTICS WITH PLYMOUTH UNIVERSITY

ROCO222 Intro to Sensors and Actuators

Force and Torque Sensors

Séverin Lemaignan

Centre for Neural Systems and Robotics **Plymouth University** 

# TODAY'S OBJECTIVES

- Know how to measure force and torque
- (prep' for ROCO318 next year)



#### DEFINITION OF FORCE

- A push or a pull
- The ability to do work
- Is is a vector quantity
- Has magnitude and direction





**PULL** 

- Measured in Newtons (N)
- Newton's Second Law
- · A force acting on a mass will accelerate or decelerate it
- F = ma

where F is Force (N), m is mass (Kg), a is acceleration (ms<sup>-2</sup>)


# FOUR FUNDAMENTAL FORCES IN NATURE

1. Gravity
Dominates at large distances




Electromagnetic forces
 Observed in the interactions between atoms

3 . & 4. Nuclear forces Strong & weak Both very short range



# FORCE ARISES FROM GRAVITY ACTING ON A MASS

- Force arises from gravity acting on a mass
- F = mg
  - where F is Force (N),
  - m is mass (Kg),
  - g is acceleration due to gravity ≈ 9



# MEASURING FORCE BY BALANCING KNOWN FORCE

 Use gravity acting on a known mass as source of known force





 Search for equilibrium position to find gravitational mass of test object


# MEASURING FORCE BY MEASURING STRAIN

- Stress defined as "force per area"
- Strain is defined as: "deformation of a solid due to stress"
- When we apply force
- · Induced stress results in a strain

$$E = stress / strain = (F / A_0) / (\Delta L / L_0)$$

#### Where


E is the Young's modulus (modulus of elasticity) F is the force exerted on an object under tension  $A_0$  is the cross-sectional area  $\Delta L$  is the amount by which object length changes  $L_0$  is the original length of the object




By measuring strain of a material of known properties can estimate force

# PIEZO-ELECTRIC EFFECT


Some materials generate electric charge under mechanical stress






- · Force results in a separation of charges with in structure
- Capacitive effect generates output voltage.
- · Leakage causes charge dissipation and voltage decay over time
- · Suitable for dynamic measurements

#### MEASUREMENT OF ELASTIC DEFORMATION



Hooke's law: F = -kx



Hooke's law only holds over the elastic region

# DIRECT MEASUREMENT OF ELASTIC DEFORMATION




Can simply observe extension to estimate force






Other mechanical methods Proving ring - Displacement measured directly using micrometer or dial gauge

#### STRAIN GAUGE



- This is an electrical method of force measurement
- The gauge measures strain of substrate to which it is attached
  - Provided substrate load operated in elastic region of the material, this is linearly relates to the applied force by Young's modulus
- Strain gauge measures strain because when film stretches it becomes narrower and longer and this increases its resistance
- Gauge is much more sensitive to strain is direction along the longer thin regions
- Overall during use such a sensor delivers only a fraction of percent change in resistance
- Resistance change is usually measured using a Wheatstone bridge

# WHEATSTONE BRIDGE CIRCUIT




 Wheatstone bridge converts change in resistance to change in voltage

$$I_{LeftBranch} = \frac{V_s}{R_1 + R_2}$$
 
$$V_{R2} = \frac{V_s R_2}{R_1 + R_2}$$
 
$$I_{RightBranch} = \frac{V_s}{R_3 + R_x}$$

$$V_{Rx} = \frac{V_s R_x}{R_3 + R_x}$$

$$V = \left(\frac{R_x}{R_3 + R_x} - \frac{R_2}{R_1 + R_2}\right) V_s$$


# WHEATSTONE BRIDGE CIRCUIT



$$V = \left(\frac{R_x}{R_3 + R_x} - \frac{R_2}{R_1 + R_2}\right) V_s$$


 By placing strain gauges into the bridge, changes in their resistance resulting from the strain in the substrate gives rise to changes in voltage that can be measured

#### Half-bridge strain gauge circuit



- Bridge arrangement cancels out changes that occur in all the resistive elements
- This compensates for resistance changes due to changes on temperature and also for strains in unwanted directions


#### SIMPLE CANTILEVER LOAD CELL



- If gauges are centrally mounted then
- · no change in output voltage due to a side load




# MEASURING TORQUE



- Two common ways to obtain torque measurements are by strain-gauging the shaft and by using in-line torque cells.
- Both have two technical obstacles: getting power to the gauges over the stationary/rotating gap and getting the signal back.

# MEASURING TORQUE USING A GAUGE ON SHAFT



 The gauges lie perpendicular to one another at 45 deg to the plane about which the tensional moment is applied.

# 6 DOF LOAD CELLS




1 translational DOF




3 translational & 3 rotational DOFs

# INSIDE A LARGE 6 DOF FT

Signal conditioning circuitry




Silicon strain gauges




Massive structure which deforms under stress

# INSIDE A SMALL 6 DOF FT



Silicon strain gauges

#### A SIGNAL CONDITIONING AMPLIFIER IS NEEDED



- The amplifier needed because voltage changes generates by Wheatstone bridge are small
- · Need differential input to cancel interference
- Also it can filter unwanted signal outside the bandwidth of interest

# That's all, folks!

Questions:

Portland Square B316 or severin.lemaignan@plymouth.ac.uk

Slides:

github.com/severin-lemaignan/module-introduction-sensors-actuators